
GEN 0.5 LIST OF HAND AMENDMENTS TO THE AIP

AIP Page(s) Affected	Amendment Text	Introduced by AIP Amendment NR
WMKJ AD 2 - 83	Tower Frequency to read as 118.15MHz and ATIS Frequency to read as 123.05MHz	1/06
WMKD AD 2 - 23	Amend Kuantan Ground frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 49	Amend Kuantan Ground frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 50	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 51	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 52	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 53	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 60	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 61	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 62	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 63	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 81	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 82	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 83	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 84	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 85	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 86	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 87	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 88	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 89	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
WMKD AD 2 - 90	Amend Kuantan SMC frequency 289.6 MHz to read as 263.9 MHz	1/12
AD 1.3 - 3	Delete Kuala Lumpur RMAF/Simpang	1/12
AD 1.3 - 3	Delete Kapit	3/12
WMKD AD 2 - 83	Amend chart title to read as ILS Z/LOC Z RWY 36 (RNAV STAR)	3/12
WMKD AD 2 - 84	Amend chart title to read as ILS Y/LOC Y RWY 36 (15DME ARC)	3/12
WMKD AD 2 - 85	Amend chart title to read as ILS X/LOC X RWY 36 (FM OVERHEAD VKN VOR)	3/12
WMKN AD 2 - 83	Amend chart title to read as ILS Z/LOC Z RWY 04 (RNAV STAR)	3/12
WMKN AD 2 - 87	Amend chart title to read as ILS Y/LOC Y RWY 04 (FM OVERHEAD VKR)	3/12
WMKN AD 2 - 89	Amend chart title to read as ILS X/LOC X RWY 04 (FM OVERHEAD TU)	3/12
WBGG AD 2 - 83	Amend chart title to read as ILS Z/LOC Z RWY 25 (RNAV STAR)	3/12
WBGG AD 2 - 84	Amend chart title to read as ILS Y/LOC Y RWY 25 (FM OVERHEAD VKG)	3/12