

**AERODROME/HELIPORT
CHART - ICAO**

06° 55' 25" N
116° 50' 16" E

ELEV 6 M


**KUDAT/
KUDAT AIRPORT**

RWY	DIRECTION	THR	BEARING STRENGTH
04	041° T	06° 55' 17.56" N 116° 50' 05.67" E	NIL
22	221° T	06° 55' 35.55" N 116° 50' 21.16" E	

INS COORDINATES FOR AIRCRAFT STANDS	BEARING STRENGTH	AIRCRAFT TYPE
1 6° 55' 23.94" N 116° 50' 13.11" E	NIL	DHC - 6
H 6° 55' 25.17" N 116° 50' 16.86" E	NIL	



ANNUAL RATE OF CHANGE 0.09° W
ELEVATIONS AND DIMENSIONS IN METRES
BEARINGS ARE MAGNETIC



CHANGES : CHANGE AERODROME AND THRESHOLD ELEVATIONS TO NEAREST METRE.
CHANGE RWY DIRECTION TO NEAREST DEGREE.