

AERODROME/HELIPORT
CHART - ICAO

05° 17' 44" N
100° 16' 20" E
ELEV 3 M

TWR	121.1
SMC	121.6
	121.9
ATIS	126.4

PENANG/PENANG
INTERNATIONAL AIRPORT

RWY	DIRECTION	THR	BEARING STRENGTH
04	42°	05° 17' 09.41" N 100° 16' 00.14" E	PCR 787/R/A/W/U -50 M CONCRETE (RIGID) PCR 577/F/A/W/U -3304 M ASPHALT (FLEXIBLE)
22	222°	05° 18' 30.25" N 100° 17' 13.37" E	PCR 577/F/A/W/U -3304 M ASPHALT (FLEXIBLE) PCR 787/R/A/W/U -50 M CONCRETE (RIGID)

HS1 CAUTION-VEHICLE MOVEMENT BEYOND THE SAFETY LINE ALONG
APRON TAXIWAY K

HS2 CAUTION-MULTIPLE AIRCRAFT CROSSING

HS3 AIRCRAFT CROSSING RWY TO TWY J MUST HOLD SHORT AT TWY B

