AERODROME/HELIPORT CHART - ICAO

05° 55' 55"N
116° 03' 01"E

ELEV 4 M

TWR	118.3
SMC	121.6
ATIS	127.4

KOTA KINABALU/KOTA KINABALU INTERNATIONAL AIRPORT

RWY	DIRECTION	THR	BEARING STRENGTH
02	023°T	05° 55' 05.35" N 116° 02' 35.35" E	PCN 86/F/C/X/T ASPHALT
20	203°T	05° 56' 50.60" N 116° 03' 19.79" E	

HOT SPOTS

HS 1 AIRCRAFT ENTERING RWY 02 MUST STOP AT HOLDING POSITION TWY J

HS 2 AIRCRAFT EXITING TAXILANE MUST HOLD SHORT TAXIWAY M

HS 3 AIRCRAFT EXITING TO APRON T2 SHALL TAKE EXTRA PRECAUTIONS DUE TO GA MOVEMENT AT THIS AREA



LEGEND	
CONCRETE STRUCTURE	⌘

CHANGES : NEW PARKING APRON