

TAXIWAY ROUTES - ARRIVALS RUNWAY 14L

All aircraft to vacate runway via intersections A6 or A7. Exits via A8, A9, and A11 may be approved on request

| RUNWAY | APRON | GATES | TAXI ROUTE DETAIL |
|------------------------------------|--|--|--|
| 14L | EAST TERMINAL SOUTH (ETS) 122.15 MHz | A2 - A14 (EVEN NR) & A51, A52, A53, A54 | Exit onto A then: B8/B11/B13 (Turn right onto B - if required), F, T5, T7 |
| | EAST TERMINAL WEST (ETW) 122.15 MHz | A3 - A13 (ODD NR) | Exit onto A then: B8, F, T6, T9, T8 |
| | EAST TERMINAL NORTH (ETN) 122.15 MHz | B3 - B23 (ODD NR) includes stands B61, B62 & B63 | Exit onto A then: B6/B8 (Turn right onto B - if required), T1, T12 B747 for stands B61/B62/B63: B8/B11/B13 (Turn right onto B - if required), T2, T3 |
| | EAST TERMINAL EAST (ETE) 122.15 MHz | B2 - B16 (EVEN NR) & B51, B52, B53, B54 | Exit onto A then: B8, F, T4, T2 |
| | VIP 122.15 MHz | A61, A62 & A63 | Exit onto A, then: B8/B11/B13 (Turn right onto B - if required), F, T6, T7, D, T13 |
| | EAST SATELLITE SOUTH (ESS) 122.27 MHz | C1, C3, C7, C32, C34, C36, C38, C51, C52, C53 | Exit onto A then: B14, K, H5, H, S5, S9, (S4, dependant on stand #) |
| | EAST SATELLITE WEST (ESW) 122.85 MHz | C2, C4, C6, C11, C13, C15, C61, C62 | Exit onto A then: B8/B11/B13 (Turn right onto B - if required), F, F4, S6, S10, (S7, dependant on stand #) |
| | EAST SATELLITE NORTH (ESN) 122.85 MHz | C12, C12R, C14, C16, C16R, C18, C21, C23, C25, C72, C73, C74 | Exit onto A then: B8/B11/B13 (Turn right onto B - if required), F, F2, S8, (S1, dependant on stand #) |
| | EAST SATELLITE EAST (ESE) 122.27 MHz | C22, C24, C26, C28 C31, C33, C35 C81, C82, C83 | Exit onto A then: B11/B13, B, S2 (S3 dependant on stand #) |
| | SATELLITE (C17) 122.85 MHz | C17 | Exit onto A then: B8/B11/B13 (Turn right onto B - if required) F, F4, G |
| | SATELLITE (C27) 121.65 MHz | C27 | Exit onto A then: B11/B13, B |
| | SATELLITE (C37) 122.27 MHz | C37 | Exit onto A then: B14, K, H5, H |
| | EAST CARGO SOUTH (ECS) 121.8 MHz | F8, F9, F10, F11 | Exit onto A then: B14, K, E |
| | EAST CARGO WEST (ECW) 123.25 MHz | F1 - F7 | Exit onto A then: B14, K |
| | EAST CARGO NORTH (ECN) 123.25 MHz | F21 - F27 | Exit onto A then: B14, K |
| EAST CARGO EAST (ECE) 123.25MHz | F28 - F34 | Exit onto A then: B14, B (N1/N2), L | |