

## TAXIWAY ROUTES - ARRIVALS RUNWAY 14L

All aircraft to vacate runway via intersections A6 or A7. Exits via A8, A9, and A11 may be approved on request

| RUNWAY | APRON                                       | GATES   | TAXI ROUTE DETAIL   |
|--------|---|---|---|
| 14L    | EAST TERMINAL SOUTH<br>(ETS)<br>122.15 MHz  | A2 - A14 (EVEN NR)<br>& A51, A52, A53, A54                            | Exit onto A then:<br>B8/B11/B13 (Turn right onto B - if required), F, T5, T7  |
|        | EAST TERMINAL WEST<br>(ETW)<br>122.15 MHz   | A3 - A13 (ODD NR)   | Exit onto A then:<br>B8, F, T6, T9, T8  |
|        | EAST TERMINAL NORTH<br>(ETN)<br>122.15 MHz  | B3 - B23 (ODD NR)<br>includes stands<br>B61, B62 & B63                | Exit onto A then:<br>B6/B8 (Turn right onto B - if required), T1, T12<br><br>B747 for stands B61/B62/B63: B8/B11/B13<br>(Turn right onto B - if required), T2, T3 |
|        | EAST TERMINAL EAST<br>(ETE)<br>122.15 MHz   | B2 - B16 (EVEN NR)<br>& B51, B52, B53, B54                            | Exit onto A then:<br>B8, F, T4, T2  |
|        | VIP<br>122.15 MHz                           | A61, A62 & A63  | Exit onto A, then:<br>B8/B11/B13 (Turn right onto B - if required), F, T6, T7,<br>D, T13  |
|        | EAST SATELLITE SOUTH<br>(ESS)<br>122.27 MHz | C1, C3, C7,<br>C32, C34, C36, C38,<br>C51, C52, C53                   | Exit onto A then:<br>B14, K, H5, H, S5, S9, (S4, dependant on stand #)  |
|        | EAST SATELLITE WEST<br>(ESW)<br>122.85 MHz  | C2, C4, C6,<br>C11, C13, C15,<br>C61, C62                             | Exit onto A then:<br>B8/B11/B13 (Turn right onto B - if required), F, F4, S6,<br>S10, (S7, dependant on stand #)  |
|        | EAST SATELLITE NORTH<br>(ESN)<br>122.85 MHz | C12, C12R, C14,<br>C16, C16R, C18,<br>C21, C23, C25,<br>C72, C73, C74 | Exit onto A then:<br>B8/B11/B13 (Turn right onto B - if required), F, F2, S8,<br>(S1, dependant on stand #)   |
|        | EAST SATELLITE EAST<br>(ESE)<br>122.27 MHz  | C22, C24, C26, C28<br>C31, C33, C35<br>C81, C82, C83                  | Exit onto A then:<br>B11/B13, B, S2 (S3 dependant on stand #)   |
|        | SATELLITE<br>(C17)<br>122.85 MHz            | C17   | Exit onto A then:<br>B8/B11/B13 (Turn right onto B - if required) F, F4, G  |
|        | SATELLITE<br>(C27)<br>121.65 MHz            | C27   | Exit onto A then: B11/B13, B  |
|        | SATELLITE<br>(C37)<br>122.27 MHz            | C37   | Exit onto A then: B14, K, H5, H   |
|        | EAST CARGO SOUTH<br>(ECS)<br>121.8 MHz      | F8, F9, F10, F11  | Exit onto A then:<br>B14, K, E  |
|        | EAST CARGO WEST<br>(ECW)<br>123.25 MHz      | F1 - F7   | Exit onto A then:<br>B14, K   |
|        | EAST CARGO NORTH<br>(ECN)<br>123.25 MHz     | F21 - F27   | Exit onto A then:<br>B14, K   |
|        | EAST CARGO EAST<br>(ECE)<br>123.25MHz       | F28 - F34   | Exit onto A then:<br>B14, B (N1/N2), L  |