

**AERODROME/HELIPORT
CHART - ICAO**

05° 17' 44" N
100° 16' 20" E

ELEV 3 M



TWR 121.1
SMC 121.6
121.9
ATIS 126.4

**PENANG/PENANG
INTERNATIONAL AIRPORT**

RWY	DIRECTION	THR	BEARING STRENGTH
04	42°	05° 17' 09.41" N 100° 16' 00.14" E	PCN 93/R/A/W/T-50M CONCRETE(RIGID) PCN 93/F/A/W/T-3304 ASPHALT (FLEXIBLE)
22	222°	05° 18' 30.25" N 100° 17' 13.37" E	PCN 93/F/A/W/T-3304M ASPHALT (FLEXIBLE) PCN 93/R/A/W/T-50M CONCRETE(RIGID)

HS1 CAUTION-VEHICLE CROSSING APRON TAXIWAY
HS2 CAUTION-MULTIPLE AIRCRAFT CROSSING
HS3 AIRCRAFT CROSSING RWY TO TWY J MUST HOLD SHORT AT TWY B

ANNUAL RATE OF CHANGE -0° 1' 18"W DECREASING
ELEVATIONS AND DIMENSIONS
IN METERS
BEARINGS ARE MAGNETIC



CHANGES: UPDATE TAXIWAY WIDE